

PVC-60x40x90mm

5.8CM



8.8CM


3.8CM

4.5CM

BARCODE AREA

- DON'T make the bar code smaller than 2,2 x 0,7 cm, including quiet zones left and right of barcode.
- Make it CLEAR & SCANNABLE.
- Barcode MUST BE PLACED within red area. DO NOT PRINT RED LINES
- If barcode is smaller on productions samples and not scannable we do not hold any responsibility.
- Background should be always white and barcode lines should be always black as in the design
- Ink should be appropriate and the production printer has to be serviced in order for any problem to be avoided during production
- For inkjet printers, make sure the cartridges are full enough and the print heads are clean.
- For laser printers, make sure the toner level is adequate and the printer rollers are clean.
- For roll printers, make sure that the ink ribbons are working properly.
- HIGH DENSITY

IT IS YOUR RESPONSIBILITY THE LINES TO BE CLEAR AND SCANNABLE AND THE BARCODE TO BE CLEAR AND SCANNABLE. IF THE BARCODE IS NOT READABLE OR SCANNABLE FROM OUR MACHINES YOU ARE GOING TO ACCEPT THE PENALTY THAT THE BUYER WILL SEND YOU.



50X51MM - LEAFLET

SIDE A

GR - ΠΡΟΕΙΔΟΠΟΙΗΣΗ ΜΠΑΤΑΡΙΑΣ: ΠΡΟΣΟΧΗ!
 1. Μην επαναφορτίζετε μπαταρίες που πρέπει να φορτίζονται.
 2. Μην υπερβείτε διαφορετικούς τύπους μπαταριών (π.χ. Κανονικές με αλκαλικές).
 3. Να κρατάτε τις παλιές μπαταρίες και να μην τις υπερβείτε με νέες.
 4. Προσοχή μην βραχυκυκλώσετε τους πόλους. Ακολουθήστε τις ενδείξεις πολικότητας μπαταριών.
 5. Αλλάξτε τις μπαταρίες όταν δεν λειτουργούν καλά ή σε περίπτωση διαρροής.
 6. Μην αφήνετε τις μπαταρίες κοντά σε πηγές θερμότητας και ποτέ μην τις πετάτε στη φωτιά.
 7. Παρακαλώ να πλύνετε αμέσως αν το υγρό από τις μπαταρίες έρθει σε επαφή με τα χέρια ή τα ρούχα σας.
 8. Η αντικατάσταση των μπαταριών να γίνεται από ενήλικα. Κρατήστε τις μακριά από τα παιδιά.
 9. Σε περίπτωση κατάποσης παρακαλώ συμβουλευτείτε γιάρω αμέσως.
 GB - ПРЕДУПРЕЖДЕНИЯ ЗА БАТЕРИИТЕ:
 1. Обновените батерии не трябва да се зареждат.
 2. Не смесвайте различни тип батерии.
 3. Винаги отстранявайте изхабените батерии от продукта. Не използвайте нови и стари батерии заедно.
 4. Внимавайте да не предизвикате късо съединение на полюсите. Спазвайте указанията поляритет в отделението за батерии.
 5. Сменете батериите, които не работят правилно или са се окислили.
 6. Не поставяйте батериите в близост до източници на топлина и никога не ги изхвърляйте в огън!
 7. Незабавно се измийте в случай на контакт на течността от батериите с ръцете или дрехите.
 8. Смяната на батериите трябва да се извършва от възрастен. Пазете ги далеч от деца.
 9. В случай на поглъщане незабавно потърсете медицинска помощ.

SIDE B

RO - AVERTISMENTE BATERII:
 1. Bateriile nereîncărcabile nu se reîncarcă.
 2. Nu folosiți diferite tipuri de baterii.
 3. Bateriile uzate vor fi îndepărtate din aparat, nu le utilizați cu baterii noi.
 4. Urmăți indicațiile privind polaritatea bateriilor. Evitați scurtcircuitule.
 5. Schimbați bateriile dacă nu funcționează adecvat sau prezintă scurgeri.
 6. Nu țineți bateriile lângă foc sau surse de căldură, nu le aruncați în foc.
 7. Clățiți imediat dacă lichidul din interior intră în contact cu pielea sau hainele.
 8. Schimbarea bateriilor se va efectua doar de adulți. A nu se lăsa la îndemâna copiilor.
 9. În caz de ingerare adresăți-vă medicului de urgență!
 GB- CAUTION BATTERY:
 1. Non-rechargeable batteries are not to be recharged
 2. Never mix different types of batteries
 3. Empty batteries are to be removed from the item. Do not mix them with the new ones.
 4. Never short-circuit the contacts. Follow the battery polarity indications.
 5. Change the batteries if they do not work properly or they have leak.
 6. Never put the batteries near the fire or heat sources, nor throw them into the fire.
 7. Please wash immediately if the skin or clothes touched the liquid from the battery.
 8. Changing of batteries to be done by adults. Keep away from children.
 9. In case of swallowing seek medical attention immediately!

